

distributed by:

State of Nine, Ltd
The Source for Saab Enthusiasts
www.stateofnine.com

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

1) Slide the inverted brake boot on to the brake arm as shown in the photo. Position the supplied tie strap on the white line marked on the neck of the boot.

Infilare il soffietto rovesciato fino alla posizione come da foto. Posizionare la fascetta sul rigo bianco presente sul soffietto rovesciato.



2) With the white line just above the bend in the brake arm, tighten the tie strap firmly and cut the excess from the strap.

Stringere fortemente la fascetta e tagliare l'eccedenza.



3) Invert the boot to the finished side and insert the metal seating around the brake by exerting light pressure.

Rivoltare il soffietto e inserirlo nella propria sede esercitando una leggera pressione per fissarlo.



4) Use the enclosed mounting screw and washer to secure the front part of the boot assembly. **Please note:** There is a small hole drilled in the metal frame. Please line the screw up to the hole before tightening (see arrow in photo at right). Tighten the screw to secure the brake boot frame to your Saab.

*Per aumentare la solidità del montaggio e' possibile fissare la parte anteriore con la vite fornita.
Si noti che la cornice in metallo ha un foro nella posizione indicata da una freccia nella foto.*



5) Installation complete! **Note** the direction of the installed brake boot to help you determine the front and back orientation. Also note that the top of the brake arm handle should be exposed as shown in the photo. Enjoy the enhanced look of your Saab!

Ora il vostro soffietto é montato. Notare che la maniglia deve essere scoperta come nella foto.

