



0610 Sistema de combustible - Conducto de combustible - Filtro de combustible (1998 - 2002),

DIESEL

Pos	Pieza N°.	Artículo	Utilización	Ctd
1	49 64 078	Conducto de combustible Note: Ch. --12020000		1
2	43 74 203	Tornillo de banjo Note: Ch. --12020000	NLS-USE 12794638	1
3	48 98 987	Tornillo de banjo Note: Ch. --12020000		1
4	81 24 133	Junta	NLS-USE 11066422	2
5	81 24 141	Junta	NLS-USE 92150435	2
6	47 51 376	Fijación		1
7	79 71 294	Tornillo		1
8	49 60 837	Conducto de combustible Presión Note: Ch. --12020000		1
9	43 97 980	Conducto de combustible Retorno Note: Ch. --12020000		1
10	49 60 779	Abrazadera		7
11	48 07 939	Cinta tensora		1
12	79 71 880	Cinta tensora	NLS-USE 92150191	2
13	43 97 741	Conducto de combustible Calefactor		2
15	49 60 878	Abrazadera		1
16	42 27 849	Clip		1
17	43 97 766	Tubo		1
19	42 29 985	Fijación		2
20	49 60 829	Conducto de combustible		1
21	79 74 546	•Anillo tórico		2
22	47 27 731	Conducto de combustible		1
23	48 99 894	Abrazadera de la manguera	NLS-USE 92152409	1
24	48 98 953	Filtro de combustible		1
24A	51 95 508	•Depósito		1
24B	54 64 656	•Filtro	(51 95 516), NLS-USE 90542912	1
24C	51 95 524	•Tapa		1
24D	51 95 532	•Tornillo		1
24E	51 95 540	•Tornillo		1
24F	51 95 557	•Resorte (muelle)		1
25	46 72 341	Bomba de combustible		1
25A	400 128 823	•Colador		1
25B	400 128 831	•Manguito		1
26	47 27 764	Abrazadera de la manguera		1
27	42 35 768	Espaciador de goma	NLS-USE 12791735	1
28	79 77 929	Tuerca	NLS-USE 92150133	2
29	95 44 248	Manguera Note: Ch. --12051712 Ch. --17017591	(47 73 347), NLS-USE 5342860	X
30	95 44 271	Distribuidor	(47 73 362)	1